



New

easy to use **Cli~mate Egg** dehumidifier

- **Ideal for small enclosed areas!**
- **Lasts up to 2 weeks before re-drying required!**
- **Indicates when drying required!**
- **Re-useable for years!** Replaces all throw away, salty chemical dry packs sold by supermarkets.

For those myriad of small enclosures the Cli~Mate Egg offers a compact and non-messy alternative to protect many household items from mould growth and musty odours.

(Product Details)

This micro dehumidifier operates by using advanced ceramic & water glass technologies (tiny rice-like carbonate silicon (SiO₂) granules) that are non toxic and non degradable. Unlike "other" moisture absorbing products they are fully recyclable and economical. A window colour-change indicates when ready for 'recharge'.

Price **Each \$28 incl gst, x 2 = \$54, x4 = \$104.**

Specifications:

- Model – Cli-mate DH200.
- Suitable for – Small areas, refer to list.
- Capacity – 50ml before drying for re-use
- Dimensions - H130mm x W110mm x D85mm.
- Weight – 0.35kgs.
- Colours – White with blue holder.
- Fully enclosed unit.
- No power, wires or batteries.
- Warranty not applicable.

Additional information


The inner content of the Cli~mate Egg is

- non-toxic,
- odourless,
- non degradable,
- recyclable and
- economical.

Ideal for use in:-

- Wardrobes, Pantries, Bathrooms.
- Book Cases, Linen closets
- Camping & Sporting Equipment, Boats, Tackle,
- Camera bags, Photo & Craft Storage
- Pianos & other Musical Equipment
- Electronic & Electrical Equipment, (great behind TV and computer)
- Leather Goods, Jewellery, Shoes
- Storage Boxes, Document storage

Dampness indicator is situated on both sides of Egg holder. Indicator will change from blue to pink when egg is full of moisture indicating that it is ready to re-dry.



To Re-dry:

Dry the egg and inner beads only! You must remove egg from holder!

Method 1

Place Egg on a paper towel in **microwave oven**, set on medium heat for 5-10 minutes. Remove from microwave and allow to cool for 5 mins, Place back in holder. Indicator should turn blue after 10 mins.

Method 2

Remove silicon end plug and invert the egg in an oven proof cup . Place carefully in conventional oven on low heat (100- 120°C) for 10 mins. Carefully remove from oven and allow to cool for 5 mins, before reinserting silicon end plug, and place back in holder. Indicator should turn blue after 10 mins.

